

**Life Fitness 9100 Series Heart Rate and Telemetry Equipped Treadmills
TROUBLESHOOTING GUIDE**

Symptom: Display Will Not Program Password or Locked In Password Mode

Malfunction	Probable Cause	Corrective Action
<p>Display will not accept password entries</p>	<p>Incorrect entries</p> <p>Pressing 0 as an entry.</p> <p>Incorrect password entered. Enter new password.</p>	<ul style="list-style-type: none"> <input type="checkbox"/> Only 3 digits are acceptable as a password (entries 1 through 999). <input type="checkbox"/> Pressing 0 before pressing other numeric keys will disable the password protection program. <input type="checkbox"/> Press CLEAR twice. <input type="checkbox"/> Press 9100 ENTER for access to password mode. <input type="checkbox"/> Enter new password. A valid password is 3 digits: 1 through 999. <input type="checkbox"/> Press ENTER.
<p>Locked in password mode</p>	<p>Incorrect entries.</p>	<ul style="list-style-type: none"> <input type="checkbox"/> Press CLEAR twice. <input type="checkbox"/> Press 9100 ENTER for access to password mode. <input type="checkbox"/> Press 0 then CLEAR to reset password mode. <input type="checkbox"/> Press ENTER. <p>Call Life Fitness Customer Support Services 847-451-0036 or 1-800-351-3737</p>